



Drill 1" or 5/8" through bottom of handrail.
Drill 1/2" pilot hole into newel post.
Use #14 hex head lag screw.
Plug bottom of rail with 1" flush plug or
5/8" flush plug or insert fillet if plowed.